


ASSEMBLY INSTRUCTIONS


- 1. Drill Holes:** Use the drill template to create holes.
- 2. Mount Assembly:** Attach the assembly from the front of the COP.
- 3. Insert LEDs:** Using the provided LEDs, feed the wiring through the front panel. Push the LEDs through and tighten the mount nut from the back.
- 4. Secure Plate:** Use the supplied M4 washers and nuts to fix plate to COP from the rear.
- 5. Connect Cabling:** Attach the cabling to the emFONE EM-181/S (see below).




DO NOT SCALE DRAWING			
REVISION 1.0.2439.3			
NAME	DATE	TITLE:	
DRAWN Stephanie N	25/09/2024	CS-CSP-P DIMENSION DRAWING	
UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN MILLIMETERS SURFACE FINISH: NATURAL TOLERANCES: ±0.5MM			A.B.N 61 164 165 100 16 ALEXANDRA PARADE, CLIFTON HILL, VIC 3068 PH: +61 3 8347 9008 E: info@pixeltechnologies.com.au W: www.pixeltechnologies.com.au
WEIGHT:	SCALE:1:1.5	DWG NO. 1 A4 SHEET 1 OF 2	

COP DRILL TEMPLATE

(TRUE SCALE)



DO NOT SCALE DRAWING			PIXEL TECHNOLOGIES	
REVISION 1.0.2439.3			TITLE: CS-CSP-P DRILL TEMPLATE	
	NAME	DATE		
DRAWN	Stephanie N	25/09/2024		
UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN MILLIMETERS SURFACE FINISH: NATURAL TOLERANCES: ± 0.5 MM				A.B.N 61 164 165 100 16 ALEXANDRA PARADE, CLIFTON HILL, VIC 3068 PH: +61 3 8347 9008 E: info@pixeltechnologies.com.au W: www.pixeltechnologies.com.au
WEIGHT:			SCALE: 1:1	SHEET 2 OF 2
			DWG NO. 2	A4